


CODE **59779**

DESCRIPTION: **SHOWER 4 SPRINKLER 4 TIMING SWITCH**



ENGLISH

POS	CODE	DESCRIPTION	POS	CODE	DESCRIPTION
1	4401040235	SPRINKLER ABS	10	4401040258	1/2" H - 1/2" H L=600 FLEX "
2	4401040256	SHOWER CAP	11	4401040259	REDUCING NUT 3/4" M - 1/2" M BRAS "
3	4401040255	3/8" H - 1/2" H L=1025 FLEX "	12	4401040260	COLLECTOR 3/4" - 3 OUTLETS 1/2" "
4	4401040248	3/8" H - 1/2" H L=875 FLEX "	13	4401040261	3/4" H - 3/4" H DN13 L-450 FLEX "
5	4401040244	SWITCH BODY	14	4401040262	ESCUTCHEON
6	4401040239	TIMING SWITCH	15	4401041307	SHOWER ANCHOR BOLTS
7	4401040238	BUTTON BODY FIXING SET	16	4402010056	EARTH CONNECTION
8	4401040240	BUTTON FRONT	17	59779R0200	SHOWER ANCHOR
9	4401040257	1/2" H - 1/2" H L=400 FLEX "	18	59779R0100	SHOWER UNIT